Board fixings: specify the system

The screw, board and support must work together.

Build Supply | SulfRock | Intelligent Panel Systems | HomePod

1 Match the support

Choose the approved fixing for timber, steel or aluminium. Confirm engagement and pull-out capacity.

2 Match the exposure

Specify corrosion performance appropriate to the location, especially coastal and wet environments.

3 Use the fixing schedule

Board size, wind load, support spacing and edge distances determine the design.

4 Head position

Set the head as required by the product guide. Do not assume every board needs a flush or countersunk fixing.

5 Allow movement

Use the prescribed hole sizes and fixed/sliding points where applicable. Avoid over-tightening.

6 Inspect the result

Check damaged edges, alignment, missed supports and overdriven fixings before concealing or finishing.

Before installation: agree the fixing type, corrosion protection, support and fixing schedule.

REFERENCE GUIDANCE

Swisspearl: facade fastening systems

Use current product instructions and the approved project design. For regulations, confirm the UK nation, applicable edition and transitional arrangements.

Help us keep our information accurate.

If you notice an error, outdated information or something that needs clarification in this document, please let us know.
Report an Issue: Visit our website and select Report a Website or Document Issue.
homepodltd.com