Board fixing holes: finishing safely

Repair and finishing depend on the board and the fixing detail.

Build Supply | SulfRock | Intelligent Panel Systems | HomePod

1 Check the fixing first

Confirm correct engagement and head position. Filling does not restore an overdriven or misplaced structural fixing.

2 Avoid automatic countersinking

Countersink only where the product instructions require it. Exposed cladding fixings may need a different arrangement.

3 Prepare without damage

Remove dust and loose material using the approved method. Control cutting and sanding dust.

4 Choose compatible filler

For SulfRock and IPS, distinguish internal joint filler from external joint treatment. Confirm the current approved products, reinforcement and finishing detail for each location.

5 Finish as instructed

Follow curing, primer and coating guidance. Generic acrylic paint is not suitable for every board or assembly.

6 Inspect and record

Check cracking, surface adhesion and fixing damage. Keep drainage paths, open joints and movement points clear.

Before finishing: verify the fixing condition, then use the approved repair and coating system.

REFERENCE GUIDANCE

Swisspearl: facade fastening systems
HSE: construction dust controls

Use current product instructions and the approved project design. For regulations, confirm the UK nation, applicable edition and transitional arrangements.

Help us keep our information accurate.

If you notice an error, outdated information or something that needs clarification in this document, please let us know.
Report an Issue: Visit our website and select Report a Website or Document Issue.
homepodltd.com